



Exhaust Fan Installation

Version 8.26

Congratulations on the purchase of your plasma table! Your plasma table comes with a very powerful exhaust fan, but it's important to install it correctly before you plug it in. **DO NOT** connect or plug the exhaust fan to power until you've properly connected the exhaust fan wires to the exhaust fan relay inside the end of the table. Not installing it properly can lead to personal injury, so make sure to carefully follow our directions. As always, if you have any questions, please don't hesitate to call us for guidance.



First off, it's important to completely remove power from all components before accomplishing any of the following. Begin by locating the end of the plasma table with the exhaust hole for the fan. Behind the panel is a relay with a 2 wire cable. Begin by grasping the lower electrical connector and unplugging it from the relay like such:



The exhaust fan has two cables extending out of it - a three position power cord, and a two wire cable. Again, make sure the power cable is unplugged before continuing. Locate the two wire cable and unwrap the electrical tape, exposing the two female connectors. Pass the connectors and cable through the small hole in the electrical panel:



Finish by inserting the two connectors into the outer two electrical slots of the electrical block:



Finish the installation by plugging the black electrical block back into the relay. Due to the design of the electrical block, there is only one correct orientation of the terminals.

Remember, DO NOT connect or plug the exhaust fan to power until you've properly completed this installation. Not installing it properly can lead to personal injury, so make sure to carefully follow our directions. As always, if you have any questions, please don't hesitate to call us for guidance. Please be diligent, and be careful as performing this improperly can cause electric shock, which can potentially cause death or serious injury.

